

# New Saturn finish on the Horizon



## SATURN COLLECTION

As recent additions to the stunning Saturn range, Clipsal now offers a textural metallic finish that comes in two fantastic new colours of Horizon Silver and Horizon Black. Horizon features a flat, square edge design that will complement any modern interior.

Horizon Silver and Horizon Black come with a subtle charcoal grey frame and push buttons that perfectly match the stylish new fascia, and superbly blend in with today's interior design.

No matter what colour you choose, Horizon provides you with the most contemporary, modern switch design on the Australian market.

# HORIZON SILVER

## BLANK PLATES



**4060VX,HS**  
Blank Plate,  
Horizon Silver

## ARCHITRAVE SWITCHES



**4061AL,HS**  
Architrave Switch Plate,  
1 Gang, Horizon Silver,  
20A/16AX, 250V a.c.  
**4062AL,HS**  
Architrave Switch Plate,  
2 Gang, Horizon Silver,  
20A/16AX, 250V a.c.

## PUSH-BUTTON SWITCHES



**4061PB,HS**  
Push-button Switch,  
1 Gang, Push-button,  
Horizon Silver,  
20A/16AX, 250V a.c.



**4062PBH,HS**  
Push-button Switch,  
2 Gang, Push-button,  
Horizontal Mech  
Orientation,  
Horizon Silver,  
20A/16AX, 250V a.c.



**4062PB,HS**  
Push-button Switch,  
2 Gang, Push-button,  
Horizon Silver,  
20A/16AX, 250V a.c.



**4063PB,HS**  
Push-button Switch,  
3 Gang, Push-button,  
Horizon Silver,  
20A/16AX, 250V a.c.



**4064PB,HS**  
Push-button Switch,  
4 Gang, Push-button,  
Horizon Silver,  
20A/16AX, 250V a.c.

## LED PUSH-BUTTON SWITCHES



**4061PBL,HS**  
Push-button Switch,  
1 Gang, Push-button,  
LED, Horizon Silver,  
20A/16AX, 250V a.c.



**4062PBHL,HS**  
Push-button Switch,  
2 Gang, Push-button,  
Horizontal Mech  
Orientation, LED,  
Horizon Silver,  
20A/16AX, 250V a.c.



**4062PBL,HS**  
Push-button Switch,  
2 Gang, Push-button,  
LED, Horizon Silver,  
20A/16AX, 250V a.c.



**4063PBL,HS**  
Push-button Switch,  
3 Gang, Push-button,  
LED, Horizon Silver,  
20A/16AX, 250V a.c.



**4064PBL,HS**  
Push-button Switch,  
4 Gang, Push-button,  
LED, Horizon Silver,  
20A/16AX, 250V a.c.



**4065PBL,HS**  
Push-button Switch,  
5 Gang, Push-button,  
LED, Horizon Silver,  
20A/16AX, 250V a.c.



**4066PBL,HS**  
Push-button Switch,  
6 Gang, Push-button,  
LED, Horizon Silver,  
20A/16AX, 250V a.c.

## FAN CONTROLLER



**4061VF3CSF,HS**  
Fan Speed Controller,  
3 Speed, Horizon Silver,  
250V a.c., 75VA.

## DIMMER



**4062E450UD,HS**  
Dimmer, Universal,  
Rotary Control,  
Separately Switched.  
2 Gang Grid Switch &  
Dimmer Assembly,  
Horizon Silver,  
220-240V a.c., 450W

## COOKER SWITCH



**4061/45,HS**  
Single Pole, 45A,  
Push-button, Cooker  
Switch, Horizon Silver

## COMMUNICATION WALL PLATES



**4031VH,HS**  
Vertical/Horizontal  
1 Gang Grid &  
Plate Assembly,  
Horizon Silver



**4032VH,HS**  
Vertical/Horizontal  
2 Gang Grid &  
Plate Assembly,  
Horizon Silver



**4033VH,HS**  
Vertical/Horizontal  
3 Gang Grid &  
Plate Assembly,  
Horizon Silver



**4034VH,HS**  
Vertical/Horizontal  
4 Gang Grid & Plate  
Assembly, Horizon  
Silver

## SWITCHED SOCKETS



**4015,HS**  
Single Gang Switched  
Socket, Horizon Silver,  
250V a.c., 10A.



**4015L,HS**  
Single Gang Switched Socket,  
Horizon Silver,  
250V a.c., 10A.



**4025,HS**  
Power Outlet Double, Horizon  
Silver, 250V a.c., 10A.



**4025X,HS**  
Power Outlet Double,  
Horizon Silver  
250V a.c., 10A,  
Extra Switch.



**4025H2,HS**  
Power Outlet, 4 Gang, Horizon Silver,  
250V a.c., 10A,  
(2 x double).

# HORIZON BLACK

## BLANK PLATES



**4060VX,HB**  
Blank Plate,  
Horizon Black

## ARCHITRAVE SWITCHES



**4061AL,HB**  
Architrave Switch Plate,  
1 Gang, Horizon Black,  
20A/16AX, 250V a.c.  
**4062AL,HB**  
Architrave Switch Plate,  
2 Gang, Horizon Black,  
20A/16AX, 250V a.c.

## PUSH-BUTTON SWITCHES



**4061PB,HB**  
Push-button Switch,  
1 Gang, Push-button,  
Horizon Black,  
20A/16AX, 250V a.c.



**4062PBH,HB**  
Push-button Switch,  
2 Gang, Push-button,  
Horizontal Mech  
Orientation,  
Horizon Black,  
20A/16AX, 250V a.c.



**4062PB,HB**  
Push-button Switch,  
2 Gang, Push-button,  
Horizon Black,  
20A/16AX, 250V a.c.



**4063PB,HB**  
Push-button Switch,  
3 Gang, Push-button,  
Horizon Black,  
20A/16AX, 250V a.c.



**4064PB,HB**  
Push-button Switch,  
4 Gang, Push-button,  
Horizon Black,  
20A/16AX, 250V a.c.

## LED PUSH-BUTTON SWITCHES



**4061PBL,HB**  
Push-button Switch,  
1 Gang, Push-button,  
LED, Horizon Black,  
20A/16AX, 250V a.c.



**4062PBHL,HB**  
Push-button Switch,  
2 Gang, Push-button,  
Horizontal Mech  
Orientation, LED,  
Horizon Black,  
20A/16AX, 250V a.c.



**4062PBL,HB**  
Push-button Switch,  
2 Gang, Push-button,  
LED, Horizon Black,  
20A/16AX, 250V a.c.



**4063PBL,HB**  
Push-button Switch,  
3 Gang, Push-button,  
LED, Horizon Black,  
20A/16AX, 250V a.c.



**4064PBL,HB**  
Push-button Switch,  
4 Gang, Push-button,  
LED, Horizon Black,  
20A/16AX, 250V a.c.



**4065PBL,HB**  
Push-button Switch,  
5 Gang, Push-button,  
LED, Horizon Black,  
20A/16AX, 250V a.c.



**4066PBL,HB**  
Push-button Switch,  
6 Gang, Push-button,  
LED, Horizon Black,  
20A/16AX, 250V a.c.

## FAN CONTROLLER



**4061VF3CSF,HB**  
Fan Speed Controller,  
3 Speed, Horizon Black,  
250V a.c., 75VA.

## DIMMER



**4062E450UD,HB**  
Dimmer, Universal,  
Rotary Control,  
Separately Switched.  
2 Gang Grid Switch &  
Dimmer Assembly,  
Horizon Black,  
220-240V a.c., 450W

## COOKER SWITCH



**4061/45,HB**  
Single Pole, 45A,  
Push-button, Cooker  
Switch, Horizon Black

## COMMUNICATION WALL PLATES



**4031VH,HB**  
Vertical/Horizontal  
1 Gang Grid &  
Plate Assembly,  
Horizon Black



**4032VH,HB**  
Vertical/Horizontal  
2 Gang Grid &  
Plate Assembly,  
Horizon Black



**4033VH,HB**  
Vertical/Horizontal  
3 Gang Grid &  
Plate Assembly,  
Horizon Black



**4034VH,HB**  
Vertical/Horizontal  
4 Gang Grid &  
Plate Assembly,  
Horizon Black

## SWITCHED SOCKETS



**4015,HB**  
Single Gang Switched  
Socket, Horizon Black,  
250V a.c., 10A.



**4015L,HB**  
Single Gang Switched Socket,  
Horizon Black,  
250V a.c., 10A.



**4025,HB**  
Power Outlet Double, Horizon  
Black, 250V a.c., 10A.



**4025X,HB**  
Power Outlet Double,  
Horizon Black  
250V a.c., 10A,  
Extra Switch.



**4025H2,HB**  
Power Outlet, 4 Gang, Horizon Black,  
250V a.c., 10A,  
(2 x double).




### Clipsal Saturn LED

The indicator light will conveniently turn on when the push button switch is activated, so you'll never have to guess which switch is in use. The pilot light has a permanent subtle, blue glow that illuminates the switch buttons for easy operation when you get caught in the dark.

### Colours and Styles

Available in Horizon Silver and Horizon Black for all switches, switched sockets, dimmers, fan controllers, cooker switches, and communication plates.

Current Rating - Power point	10A
Current Rating - Switches	20A/16AX
Voltage	250V a.c.
Fascia Colours	HS (Horizon Silver) HB (Horizon Black)
Fascia Material	Stainless Steel (Horizon Silver) Anodised Aluminium (Horizon Black)
Edge and Base Colour	Black
Dolly and Socket Colour	Charcoal
Bezel Colour	Chrome
Frame Colour	Charcoal
LED Colour (PBL Models)	Blue



### Clipsal Australia Pty Ltd

A member of Schneider Electric

#### Head Office

33-37 Port Wakefield Road,  
Gepps Cross  
South Australia 5094

♻️ printed on recycled paper

**clipsal.com**

Website clipsal.com  
Contact us clipsal.com/feedback

**National Customer Care Enquiries:  
1300 2025 25**

Clipsal Australia Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© Clipsal Australia Pty Ltd.