

Stainless steel freestanding dishwasher with 5 wash programs, including 30 minutes quick wash and water saving ECO wash. Enjoy the added benefits of time remaining display and easy lift upper basket with stable support for tall glasses.

RRP AUS \$1,069.00





# **Product Details**

#### **FEATURES**

13 place settings	Mark resistant stainless steel door	Time remaining display	Load sensing
Water safety system	Delay start	Tablet option	Durable stainless steel tub

The wash programme may be started after a designated

amount of time

# BENEFITS

#### Simple to use controls

This dishwasher features a simple push button control with a button for each program.

#### A faster wash

When you're in a hurry or only have a partial load to wash, the Quick 30 program is the perfect choice. This 60-degree wash ensures sparkling dishes every time.

#### Saves water

With today's climate challenges, we need to do what we can to save water. That's why we offer 4.5 star WELS water rated dishwashers, so you can make a better choice for your future.

#### More stable with soft spikes

Now you can prevent glasses from falling over, breaking or cracking in the dishwasher. Our clever soft spikes help keep your glasses stable and reduce the likelihood of breakages.

#### Easy-lift upper basket

The top basket height can be easily adjusted to accommodate large plates and platters in the lower basket, even when fully loaded

#### Auto Off

With the Auto Off feature the dishwasher will automatically shut off to keep energy consumption to a minimum.



# **Specifications**

## PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Dishwashers	freestanding
Place settings	13
Drying system	condensing
Number of spray arms	2
Top shower	No

## **SPECIFICATION**

Water efficiency star rating WELS	4.5
Water consumption (litres)	11.6
Energy Star Rating	3
Energy consumption cold water (kWhr/yr)	282
Noise level dBA	48
Water supply	cold or hot (maximum 60°C)
Basket colour	grey
Service cord length	1.8

## **DIMENSIONS**

Total height (mm)	850
Total width (mm)	596
Total depth (mm)	625

## **WASH PROGRAMS**

Number of Programs	5
Programs	pots,rinse and hold,quick 30 min,regular eco,regular plus



## **DIMENSIONS**

Product height excluding removabale worktop (mm)	820
Product width excluding removabale worktop (mm)	596
Product depth excluding removabale worktop (mm)	570
Height adjustment (mm)	10
Cabinet requirement excluding worktop (height)	822
Cabinet requirement excluding worktop(width)	600
Cabinet requirement excluding worktop (depth)	550
Product height including removal worktop (mm)	850
Product width including removal worktop (mm)	596
Product depth including removal worktop (mm)	625

## **WASH PROGRAMS**

Wash option	Delay start (1-24 hours),Tablet
Range of temperatures	4

## **CONTROL PANEL**

Control panel type	LED Display,Push button electronic
	0.001.01.10

## **FEATURES**

Other Features	load sensing,delay start,Auto
	Off



## **CONTROL PANEL**

Top mounted control panel	No
Control panel finish	silver
Knob or button finish	grey
Display indicators	rinse aid,time remaining,fault display,tablet function,delay start,end ,wash program

## **FEATURES**

Water safety system	overfill protection,bottom catchment tray
Filter system	3 stage
Dispenser	detergent,rinse aid
Number of spray levels	3

## **EXTERIOR**

Door finish	mark resistant stainless steel
Counter-balance door	Yes
Side colour	grey
Plinth colour (kickboard)	grey
Removable worktop	Yes
Worktop colour	grey

## **UPPER BASKET**

Upper basket features	soft spikes for tall glass,height adjustable on full load
Foldable cup shelves	2

## **LOWER BASKET**

Lower Basket Features cutlery basket

## **HOSES**

Inlet hose length (metres) 1.5



## **HOSES**

Drain hose length (metres)	1.5
extension hose	spare part

# **SHIPPING**

Shipping Volume (m3)	386
Shipping Weight (Kg)	42
Shipping Weight (Kg)	39.8
Pack Dimensions Height (mm)	894
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	680

# STUFFING QUANTITIES

20ft	54
40ft	108
40ft HC	150



# **Terms and Conditions**

#### **IMPORTANT**

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

#### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

#### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### **ELECTROLUX HOME PRODUCTS AUSTRALIA**

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

**ELECTROLUX HOME PRODUCTS NEW ZEALAND** 

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz